

Spill Containment

IBC Spill Containment Bundstand - User Health & Safety Instructions

The IBC Spill Containment Bundstand will give many years of service by just following the simple guidelines below.

Siting the IBC Spill Containment Bundstand

The IBC Spill Containment Bundstand should be sited on a flat level surface swept clean of stones and any other objects. A bed of soft sand can be used if the site is uneven. IBC Spill Containment Bundstands with their own integral forklift facility ought to be sited on a flat and level surface.

Loading the IBC Spill Containment Bundstand

Forklift users should be instructed to lower the IBC unit as carefully and as level as possible on the IBC Spill Containment Bundstand. The IBC unit must sit on the recessed pads, avoid lowering onto elevated surfaces. The forks should be withdrawn free of snagging the IBC Spill Containment Bundstand rim or any part of the IBC unit.

Forklift users should be made aware that the single IBC Spill Containment Bundstand is not square and the IBC unit should be loaded correctly. The IBC unit nozzle should face toward the narrowest side. IBC Spill Containment Bundstands with a drain off bucket facility cannot be loaded from the bucket side.

The IBC unit should not be loaded onto a IBC Spill Containment Bundstand while the IBC Spill Containment Bundstand is on a pallet.

Spillages

In the event of a spill and in harmony with good housekeeping, cleanups should occur immediately and any residual liquid neutralised. However, data sheets should be consulted and the health and safety officer or responsible person should supervise all cleanups. Waste should be disposed of in accord with the manufacturers direction.

The units are designed/supplied for secondary containment of spillage, and not for primary containment unless otherwise agreed in writing.

Use

The IBC Spill Containment Bundstand is designed to cope with a variety of environments and is suitable for 95% of all liquids to be stored. Please refer to our website www.suigeneris.co.uk which contains a chemical resistance chart showing the range of liquids that can be safely bundled.

When drawing from the IBC unit directly into a container, sensible practices should be followed such as not overfilling the container, not leaving the container whilst being filled, the wearing of appropriate gloves, etc. The filled container should not be removed from the IBC Spill Containment Bundstand without first making sure the IBC valve is turned off and not leaking fluid.

Storage

Thoroughly clean and store on a flat surface.

Moving the IBC Spill Containment Bundstand

The IBC Spill Containment Bundstand can be lifted quite comfortably by two healthy personnel. It is recommended that when moving the location of the IBC Spill Containment Bundstand it is manhandled onto a pallet and moved by forklift. If relocating please refer to Siting the IBC Spill Containment Bundstand (left).

When manhandling the IBC Spill Containment Bundstand sensible lifting practices should be employed.

Do not:- a) Drag the IBC Spill Containment Bundstand
b) Forklift without a pallet

Under no circumstances should any IBC Spill Containment Bundstand be moved while accommodating an IBC unit.



SG105
Spill containment for 2 x 1000 litre IBC. With dispensing facility.

Sui Generis International Ltd.

The Chandler's Centre
Hythe Quay
Colchester
CO2 8JB
Tel: 01206 798 798
Fax: 01206 866 666
Email: info@suigeneris.co.uk
www.suigeneris.co.uk